

ELBA

COOKER HOOD
MODEL: 1917/76MC
1917/76SS

Owner's Manual

Please read this manual carefully before operating your set.

Retain it for future reference.

Record model number and serial number of the set.

See the label attached on the set and quote this information to your dealer when you require service.

For The Warranty Terms & Conditions, Please Refer To Warranty Certificate

Please read this instruction carefully. It is advisable to keep this instruction manual in a safe place for future reference.

SAFETY PRECAUTIONS

1. Keep electrical appliances out of reach from children. Do not let them to operate the appliances without supervision.
2. To protect against the risk of electrical shock, do not immerse the product, cord or plug into water or any other liquid.
3. This product is for household and indoor use only.
4. This product is not intended for use by person (including children) with reduced physical, sensory or mental capabilities unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
5. If the power cord or plug is damaged, it must be replaced by the service centre or a qualified service technician to avoid hazard.
6. Before installation, check if the mains supply voltage is matched with the voltage stated on the rating plate of the hood.
7. There must be adequate air ventilation of the room when the cooker hood is used with the cooking appliances with burning gas or other fuels.
8. Ensure that the installation of exhaust complies with the standard of local building, gas and electrical authorities.
9. Do not ignite flames in the pans.
10. There is a risk of fire if cleaning is not carried out in accordance with this instruction.


ASSEMBLY INSTRUCTIONS

Please check the following before installation:

- Installation of hood must be carried out by an authorized or qualified technician.
- For optimum air extraction, avoid having too many windows surrounding the cooker hood which will cause air convection.
- Make sure the hood is in level after installation to avoid oil spill over from the oil cup collectors.
- The optimum height for the installation is between 650 to 750mm which measure from the bottom of the hood to the top of the hob.
- Remove all packaging materials from the cooker hood. Check if both sides of the cooker hood have a metal hook installed.

- 1) Loosen the screws on the metal hook but do not loosen completely. Allow the metal hook to move up and down slightly.
- 2) Using the metal hook provided, determine the height of the cooker hood to be installed on the wall. Mark the wall with two markers left and right then drill the hole at the size 1.4"
- 3) Plug the plastic anchor into the holes tightly. Fix the installation screws by leaving 5mm gap from the wall.
- 4) Hang the cooker hood to the installation screws of 5mm gap and tighten the screws firmly.
- 5) Plug in the wall plug and switch on the power.

PRODUCTION DESCRIPTION



- 1) Mounting Screws (Left & Right)
- 2) Switch
- 3) LED lamp
- 4) Grill Guard
- 5) Oil Cup

OPERATING INSTRUCTIONS

1. Press the ON/OFF button to turn the unit on and off.
2. Press the Left and Right button to operate the fan blower. Press again to turn off.
3. Press the Light button to illuminate the LED lamp on/off.
(Remarks: The Light function is independent from the ON/OFF button)

CLEANING AND MAINTENANCE

- The hood must always be disconnected from the electricity supply before carrying out the maintenance.
- Clean the hood with damp cloth, hot water and mild detergent. Do not use chemical, steel, wooden or abrasive cleaners to clean the hood.
- Clean the oil cups when they are more than half filled to avoid the oil from spilling.
- Remove the oil cups, wash in hot soapy water, dry and fit back into the hood. Do not use the hood without the oil cup installed.

MAIN SPECIFICATION

Rated Voltage	: 220-240V/50Hz
Light	: 2 x 1.5W
Motor	: Twin Motor
Exhaust Diameter	: 6"
Suction Power	: 885m ³ /hr
Motor Power	: 160W
Motor Speed	: 1,430 RPM
Product Dimension	: 755mm(W) x 100mm (H) x 510mm(D)
Product Weight	: 9.6KG

NOTICE

This product must not be disposed together with domestic waste. It has to be disposed at an authorized place for recycling of electrical and electronic appliances. By collecting and recycling waste, you help to save natural resources and make sure the product is disposed in an environmental friendly and healthy way.



ELBA